

"SL-5000D" Keycode for Java[™] Applications

(revision 1.0 2001.9.26)



Mobile Systems Division

	Scan Keys	On SL-5000D	Java (KeyEvent)	Remarks
1	A	on the keyboard	VK_A	
2	В	on the keyboard	VK_B	
3	С	on the keyboard	VK_C	
4	D	on the keyboard	VK_D	
5	E	on the keyboard	VK_E	
6	F	on the keyboard	VK_F	
7	G	on the keyboard	VK_G	
8	Н	on the keyboard	VK_H	
9	I	on the keyboard	VK_I	
10	J	on the keyboard	VK_J	
11	K	on the keyboard	VK_K	
12	L	on the keyboard	VK_L	
13	M	on the keyboard	VK_M	
14	N	on the keyboard	VK_N	
15	0	on the keyboard	VK_O	
16	Р	on the keyboard	VK_P	
17	Q	on the keyboard	VK_Q	
18	R	on the keyboard	VK_R	
19	S	on the keyboard	VK_S	
20	Т	on the keyboard	VK_T	
21	U	on the keyboard	VK_U	
22	V	on the keyboard	VK_V	
23	W	on the keyboard	VK_W	
24	Χ	on the keyboard	VK_X	
25	Υ	on the keyboard	VK_Y	
26	Z	on the keyboard	VK_Z	
27	Shift			Shift keys (located right or left)
	(located left)	on the keyboard	VK_SHIFT	are handled same on Java
28	Return	on the keyboard	VK ENTER	application level
29	Menu	on the keyboard	VK_F11	
30	Fn	on the keyboard	VIX_1 11	Driver to decorate the key to
		,		notify the status.
31	BS	on the keyboard	VK_BACK_SPACE	
32	Sym	Fn+Space		
33	Frontlight	Holding "Menu" button		
34	Cancel	on the keyboard cover	VK_ESCAPE	
35	Left	on the keyboard cover	VK_LEFT	
36	Up	on the keyboard cover	VK_UP	



Mobile Systems Division

	Scan Keys	On SL-5000D	Java (KeyEvent)	Remarks
37	Down	on the keyboard cover	VK_DOWN	
38	Right	on the keyboard cover	VK_RIGHT	
39	ОК	on the keyboard cover		generated WINDOW_CLOSING event
40	Home	on the keyboard cover		Shift to Launcher (desktop) screen
41	1	Fn+Q	VK_1	
42	2	Fn+W	VK_2	
43	3	Fn+E	VK_3	
44	4	Fn+R	VK_4	
45	5	Fn+T	VK_5	
46	6	Fn+Y	VK_6	
47	7	Fn+U	VK_7	
48	8	Fn+I	VK_8	
49	9	Fn+O	VK_9	
50	0	Fn+P	VK_0	
51	- (minus)	Fn+B		
52	+	Fn+N		
	Caps	Fn+Tab	VK_CAPS_LOCK	
54	@	Fn+S		
55		Shift+/(slash)		
56	, (camma)	on the keyboard		
57	(period)	on the keyboard		
58	Tab	on the keyboard	VK_TAB	
59	Cut	Fn+X		
60	Сору	Fn+C		
	Paste	Fn+V		
62	/ (slash)	on the keyboard		
63	(single quote)	on the keyboard		
64	; (semi-colon)	Shift+, (camma)		
65	" (double quote)	Shift+' (single quote)		
66	: (colon)	Shift+. (period)		
	#	Fn+D		
68	\$	Fn+F		
69	%	Fn+G		
70	_ (under score)	Fn+H		
	&	Fn+J		
72	*	Fn+K		
73	(Fn+L		
	Del	Fn+BackSpace	VK_DELETE	



Mobile Systems Division

Scan Keys		On SL-5000D	Java (KeyEvent)	Remarks
75	UNDO	Fn+Z		
76	=	Fn+M		
77)	Fn+, (camma)		
78	~ (tilder)	Fn+' (single quote)		
79	<	Fn+. (period)		
80	>	Fn+Enter		
81	Activity	on the keyboard cover		
82	Contacts	on the keyboard cover		
83	Mail	on the keyboard cover		
84	Select	on the keyboard cover	VK_ENTER	
85	(space)	on the keyboard	VK_SPACE	
86	!	on the keyboard		
87	Shift (located right)	on the keyboard	VK_SHIFT	Shift keys (located right or left) are handled same on Java application level.
88	OFF	"Cancel" kept pressed		
89	Mail (kept pressed)	Mail kept pressed		
90	Numlock	Fn+/	VK_NUM_LOCK	Driver to decorate the key to notify the status.
91	Page Up	2nd+Up		
92	Page Down	2nd+Down		
94	Sync start key	Sync button on the docking station		
95	(pipe)	Shift+ (space)		
96	¥ (backslash)	Shift+TAB		